



NOTES:

1. SLOPE FROM THE PROPERTY LINE TO THE STREET AT 2%.
2. WORK AGGREGATE INTO CONCRETE PRIOR TO FINISHING CONCRETE.
3. FINISHING DETAILS.
 - EDGE CONCRETE WITH 3" EDGING TROWEL.
 - SCORE CONCRETE AT 5' INTERVALS.
 - INSTALL 1/8"x1 1/2" CONTRACTION JOINTS EVERY 15'.
 - FABRIC TYPE EXPANSION JOINT NOT TO BE USED.
 - APPLY LIGHT BROOM FINISH TRANSVERSE TO THE SIDEWALK
4. CONCRETE SHALL HAVE STRENGTH OF 3000 P.S.I. AT 28 DAYS.
5. APPLY CURING COMPOUND (PETROLEUM BASE) TO FRESH CONCRETE TO RETAIN MOISTURE.
6. TOLERANCES
 - SURFACE SHALL NOT VARY MORE THAN 1/4" FROM A 10' STRAIGHT EDGE.
 - ALIGNMENT SHALL BE WITHIN 1/4" OF TRUE LINE.

REVISIONS:

**SIDEWALK
TYPE "B"**

SCALE:	N.T.S.
DATE:	Jan. 2010
APPROVED BY:	P. Chiu
STANDARD DRAWING	504