



NOTES

1. CONCRETE SHALL HAVE STRENGTH OF 3000 P.S.I. AT 28 DAYS.
2. LIMITS OF DRIVEWAY SHALL BE SAW CUT.
3. APPLY A LIGHT BROOM FINISH TRANSVERSE TO THE SIDEWALK.
4. CURB AND APPROACH SHALL BE POURED MONOLITHICALLY.
5. IF WIDTH IS GREATER THAN 15 FEET, INSTALL CONTRACTION JOINT IN CENTER OF THE DRIVEWAY.
6. FABRIC EXPANSION JOINT SHALL NOT BE USED.
7. WORK AGGREGATE INTO CONCRETE PRIOR TO FINISHING CONCRETE.
8. APPLY CURING COMPOUND TO FRESH CONCRETE TO RETAIN MOISTURE.
9. MINIMUM DRIVEWAY WIDTH OF 12' AND MAXIMUM WIDTH OF 24'
3 CAR GARAGE MAXIMUM WIDTH OF 28"

REVISIONS:
04/08/10

**DRIVEWAY APRON
CURB CUT
TYPE "A" SIDEWALK**

SCALE:	N.T.S.
DATE:	May 2007
APPROVED BY:	D. Danicic
STANDARD DRAWING	508